

Non-Electric Scream Machine Rear Wheel Installation Tips

Left & Right Scream Machine rear wheels are exactly the same. For easier installation apply a little grease/oil to the bolts.

Using an Allen key, carefully thread the axle into the frame. When installing the right wheel turn clockwise. Installing the left wheel turn the bolt counterclockwise. Turning the Left axle to the right will strip the frame. The bolt treads must go in very straight for proper installation. If you feel like you need to apply force to turn the bolt STOP and make sure the bolt is going in the correct direction & straight into the frame. If you are having trouble installing the wheels you can try the original bolts.

When the locking nuts come in contact with the frame, check the wheel to see if it spins freely or if there is excess side-to-side play. If it spins free and there is just a slight end play, tighten the axle securely and, using a wrench, tighten both locknuts against the frame. If the wheel will not spin freely, loosen the locknuts and unthread the axle about 1/4 turn and adjust the locking nuts in or out until the wheel spins free with little or no side play. The correct adjustment is where the wheel spins free, has the least amount of endplay as possible, and both lock nuts are tightened securely against the frame.



Installing Left Wheel turn counter clockwise